

## Wired Alert Mat Plug Type Guide

When placing an order for any wired Alert Mat or accessory please ensure you match the nurse call system to the correct product code ending so you receive the correct plug.

Please do not rely on plug type alone. Even though some plugs look identical they have different wiring configurations inside specific to some nurse call systems. It is important you order the correct product code ending otherwise the Alert Mat might not work properly.

This guide will assist you in matching the nurse call system to the correct product code ending.

Nurse Call System	Product Code Ending	Plug Type
<b>ATX3000 (old)</b>	-W	White 'BT type' plug
<b>Aid-Call ATX4000</b>	-C6	RJ12 Clear Plug, 6P6C
<b>Aid-Call ATX5000 &amp; ATX3000plus Touchsafe pro</b>	-C6TSPro	RJ12 Clear Plug, 6P6C
<b>C-TEC Nursecall</b>	-Q	Double ring stereo jack plug
<b>Chubb</b>	-S	Single ring mono jack plug
<b>Courtney Thorne</b>	-C	Single ring mono jack plug
<b>Eclipse</b>	-D	Double ring stereo jack plug
<b>Gemini</b>	-D	Double ring stereo jack plug
<b>Intercall</b>	-S	Single ring mono jack plug
<b>Medicare (floor mats)</b>	-MED01	RJ9 Clear Plug, 4P4C
<b>Medicare (bed/chair mats)</b>	-MED22	RJ9 Clear Plug, 4P4C
<b>Quantec</b>	-Q	Double ring stereo jack plug
<b>Stanley Blick</b>	-SASN2	Double ring stereo jack plug

### Plug Type Identification



Single ring mono jack plug



Double ring stereo jack plug



RJ9 Clear Plug, 4P4C



RJ12 Clear Plug, 6P6C



White 'BT type' plug