

Cyclone

Extra thick bleach



Perfumed thickened bleach with added detergent.
Concentrated disinfectant.

Thickened; extends the contact time for superior cleaning and disinfecting.

Kills bacteria; passes EN 1276.
Effective against MRSA.

- Suitable for a variety of applications including wiping down washable hard surfaces.
- Ideal for removing mould and mildew from grout in kitchens and washrooms.
- If used undiluted, product provides 50,000 parts per million available chlorine.
- Supplied in an angled neck bottle for use under the toilet rim or in a 5 litre bottle.
- Effective against Coronavirus at 1,000 ppm.

CLEANING AND DISINFECTING TOILETS:

Flush first and remove excess dirt and grime before cleaning and disinfecting. Wet all surfaces of bowl interior, including sides of bowl and under the rim, with at least 100ml of bleach. Do not close the toilet bowl lid. To ensure disinfection allow to stand for at least 15 minutes. Brush entire bowl thoroughly and flush. To remove tough stains: Apply a generous amount of liquid directly onto the tough stain.

FOR HARD SURFACES:

Remove heavy soiling first, then dilute 1:50 parts of water (20ml per 1lt of warm water). Apply with a sponge or mop, wetting all surfaces thoroughly. Allow to stand for 5 minutes, then wipe away excess. For Coronavirus, dilute 23ml per 1lt of water for 1,000 ppm and clean surfaces with a detergent first, prior to disinfection.

BLEACHING LAUNDRY:

Dilute 1:100. If soaking overnight use 1:200 solution.

EQUIPMENT DISINFECTION BY SOAKING:

Remove heavy soiling first, then dilute 1:50 parts water (20ml per 1lt of warm water). Allow to soak for a minimum of 15 minutes. Remove and rinse with water.

USAGE:

Do not use on: Marble, natural stone, wood, painted surfaces, aluminium, carpet or paper. Please take care when handling product to avoid spillages on skin and clothes. Do not store near acid based products.

RELATED ITEMS:

- Bleach - General purpose.
- Cyclone Spray - Spray with bleach
- Chlor Tabs - Effervescent chlorine tablets



5l

Order Code: A154EEV2

Pack: 2 x 5 litre (11.37 kg)
Pallet: 60 Packs

750ml

Order Code: A154AEV

Pack: 12 x 750ml (11 kg)
Pallet: 75 Packs

PRODUCT INFORMATION:

Appearance: Clear yellow/green viscous liquid
Odour: Citrus
pH - undiluted: 12.7
Shelf life: 1 year

COMPOSITION:

Contains a blend of sodium hypochlorite, sodium hydroxide, viscosity stabilisers, anionic surfactant and perfume.

BIODEGRADABILITY:

All surfactants used in Evans Vanodine products comply with the current European Regulations concerning biodegradability and protection of the environment.

QUALITY ASSURANCE:

EVANS VANODINE INTERNATIONAL PLC operates under an ISO 9001 Quality Management System Cert. No. FM 09535 and an ISO 14001 Environmental Management System Cert. No. EMS 506072 registered by the British Standards Institution.

REVISION DATE:

02/06/20



Evans Vanodine International plc

Brierley Road, Walton Summit, Preston, PR5 8AH, UK
Tel: +44 (0)1772 322200



www.evansvanodine.co.uk