

# **PRODUCT USE GUIDE FOR**

# EVOLUTION EV6 BATH & WASHROOM CLEANER

# **N2**

## **Product Description**

An antibacterial and descaling product that effectively removes natural oils, soap deposits and general soil from baths, sinks, showers, WCs, tiles, glass screens and hard floor coverings. Helps prevent hard water deposits from forming on surfaces and leaves a refreshing mild fragrance to deodorise the room. Contains a fresh citrus perfume.

### **Product Features**

- Specially designed for use through the Cleenol Evolution dispensing system.
- Leaves a refreshing mild fragrance.
- The product may be dispensed by the Evolution system into the 750ml flask at a rate of 5ml, 10ml, 15ml or 20ml, depending upon the strength of finished product required. The following dilution rates are recommended:

5ml Light soiling 15ml Medium to heavy soiling

10ml Light to medium soiling 20ml Heavy soiling

- Please note that this product is bactericidal only at 20ml in 750ml
- The product has passed the European Suspension Test (BSEN 1276) when diluted 20ml to 750ml and has been found to be effective against the following bacteria after a contact time of 5 minutes:
- Pseudomonas aeruginosa, Escherichia coli, staphylococcus aureus, enterococcus hirae.

## **Direction for Use**

- Apply product to a clean, damp, sponge / cloth. Apply to wetted surface to be cleaned. Rinse surface thoroughly with clean water. Allow to air dry or buff to a finish.
  - Refilling 750ml Flask
- Following bottle filling directions on Product System Chart. When empty, fill to top line of bottle. **Reloading 1.5L Pouch**
- (1) Remove empty pouch from dispenser and dispose of as normal waste. (2) Remove screw cap. (3) Insert pouch in Evolution Dispenser No. 6. (4) Depress locking cap firmly into pouch. (5) Lock cabinet. (6) Insert over-rider key and pump until product is dispensed (ensure flask is in place).

## **Storage**

- Store in cool conditions away from direct sources of heat
- Avoid extremes of temperature
- Do not allow to freeze
- Ensure the cap is tightly fitted after use
- Keep out of reach of children









# PRODUCT USE GUIDE FOR EVOLUTION EV6 BATH & WASHROOM CLEANER N2

## **Shelf Life**

- Shelf life 24 months, if stored as recommended.
- Use within 6 months of opening.

## **Environmental**

- Neat product may cause damage to plant and animal life. Do not allow neat large quantities of product to enter surface waterways.
- In the event of a large spillage, contact the local water authority or Environmental Agency immediately.
- Evolution Products are not classified in their diluted form.
- This product uses recyclable packaging. The detergents used in the formulation are biodegradable to EU guidelines under the detergents regulations (EC) No 648/2004.
- It contains no Phosphates.

# For further information please scan your QR Smart Reader here



## **Code Nos.**

EV6 2x1.5L

EVF6 6x750ml refill flask

EV6/1000 3x1L

## Data Sheet No. N2

Note: This product is only to be used for the purpose for which it was intended and in accordance with the specified instructions. This product should never be mixed with other chemical products and should be handled with care and stored carefully out of reach of children.



## **Cleenol Group Ltd**

Beaumont Road, Banbury, Oxon, OX16 1RB. UK. Tel: +44 (0) 1295 251721 Fax: +44 (0) 1295 269561 Email: sales@cleenol.co.uk www.cleenol.co.uk



Certificate No. 316